

# CE

# QUICK START GUIDE

# Multi Differential Relay, MDR-2

- What's in the delivery?
- Getting started
- The first steps
- PC utility software



DEIF A/S · Frisenborgvej 33 · DK-7800 Skive Tel.: +45 9614 9614 · Fax: +45 9614 9615 info@deif.com · www.deif.com

Document no.: 4189340624B SW version 3.0X.X or later Table of contents

1	. ABOUT THIS DOCUMENT	. 3
	GENERAL PURPOSE INTENDED USERS CONTENTS/OVERALL STRUCTURE	. 3 . 3 . 3
2	. WARNINGS AND LEGAL INFORMATION	. 4
	LEGAL INFORMATION AND RESPONSIBILITY ELECTROSTATIC DISCHARGE AWARENESS SAFETY ISSUES DEFINITIONS	. 4 . 4 . 4 . 4
3	. WHAT'S IN THE DELIVERY?	. 5
	STANDARD DELIVERY	. 5 . 6
4	. GETTING STARTED	. 7
	CONNECTING THE DEVICES	. 7 . 8
5	THE FIRST STEPS1	11
	BASIC AC VALUES	11
6	PC UTILITY SOFTWARE 1	13
	INSTALLATION	13 14 15 16

# 1. About this document

# **General purpose**

This document is the Quick Start Guide for the Multi-line 2 product MDR-2. The general purpose of the document is to help the user with the first steps of installing and using the unit.



Please make sure that you also read the Designer's Reference Handbook before starting to work with the Multi-line 2 controller and the gen-set to be controlled. Failure to do this could result in human injury or damage to the equipment.

# Intended users

This Quick Start Guide is mainly intended for the panel builder in charge. On the basis of this document, the panel builder designer will give the electrician the information he needs in order to get started to install the unit. For detailed electrical drawings, the Designer's Reference Handbook must be used.

# **Contents/overall structure**

This document is divided into chapters, and in order to make the structure simple and easy to use, each chapter will begin from the top of a new page.

# 2. Warnings and legal information

This chapter includes important information about general legal issues relevant in the handling of DEIF products. Furthermore, some overall safety precautions will be introduced and recommended. Finally, the highlighted notes and warnings, which will be used throughout this document, are presented.

# Legal information and responsibility

DEIF takes no responsibility for installation or operation of the generator set. If there is any doubt about how to install or operate the generator controlled by the unit, the company responsible for the installation or the operation of the set must be contacted.

# The units are not to be opened by unauthorised personnel. If opened anyway, the warranty will be lost.

## Electrostatic discharge awareness

Sufficient care must be taken to protect the terminals against static discharges during the installation. Once the unit is installed and connected, these precautions are no longer necessary.

# Safety issues

Installing the unit implies work with dangerous currents and voltages. Therefore, the installation of the unit should only be carried out by authorised personnel who understand the risks involved in the working with live electrical equipment.



Be aware of the hazardous live currents and voltages. Do not touch any AC measurement inputs as this could lead to injury or death.

# Definitions

Throughout this document a number of notes with helpful user information will be presented. To ensure that these are noticed, they will be highlighted in order to separate them from the general text.

### Note symbol



The notes provide general information which will be helpful for the reader to bear in mind.

### Warnings



The warnings indicate a potentially dangerous situation which could result in death, personal injury or damaged equipment if certain guidelines are not followed.

# 3. What's in the delivery?

# Standard delivery

# The main unit



Standard display unit, DU-2



# **Optional delivery**

Display cable, 3 m (option J1)



Display cable, 6 m (option J2)



Display cable, 1 m (option J6)



4.

# Connecting the devices

**Getting started** 

# Connecting the display to the main unit

Connect the SUB-D display cable to the main unit and the display unit as shown in the below picture.



# **Basic wiring**

# AC wiring



Generator

# AC wiring – option C4





Only -/1A CTs can be used with option C4.

# **DC** wiring



# 5. The first steps

# **Basic AC values**

This chapter guides you through the most essential parameters which have to be adjusted before you can start using the unit.

The setpoints can either be adjusted from the display unit or by using the DEIF utility software. The following examples will show how to adjust the parameters from the display unit.



All settings are reached by placing the cursor under SETUP (in the main page) and pressing ENTER

	DEIF		Multi Di	ifferential Relay				
	12 2010 SYS	0 -07-27 TEM SE	0 TUP	<i>multi-line MDR</i> <b>0%</b> 10:13:32				
	PROT			→ <u>SYST</u>				
Place the cursor under SYST and press ENTER								

DEIF		Multi Diffe	rential Relay
		т	ulti-line MDR
12	0	0	0%
4010	Nom. s	settings	
Freq	uency	ļ	50.0Hz
<u></u>			

Place the cursor under the setting you require and press ENTER

# **Nominal settings**

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4010	4010 Nominal settings						
4011	Nom. settings	Frequency	48.0 Hz 62.0 Hz	50.0 Hz		Designer's Reference	
4012	Nom. settings	Current	1 A 10000 A	787 A		Handbook	

To adjust the transformer settings, use the rightarrow or rightarrow push-button to get to the transformer page.

# VT and CT settings

No.	Setting		Min. Max.	Factory setting	Notes	Ref.	Description
4020	Transformer						
6041	Transformer	Current primary	5 A 10000 A	1000 A		Designer's Reference	
6043	Transformer	Current secondary	1 A 5 A	1 A		Handbook	

# 6. PC utility software

# Installation

- 1. Go to <u>www.deif.com</u>
- 2. Select "Download centre"
- 3. Select "Software download"
- 4. Select "Multi-line 2 Utility Software v.1.x" in the dropdown list
- 5. Fill in your e-mail address and click "Submit".

Subsequently, you will receive an e-mail containing a link. Click the link and follow the instructions to install the programme.

# Getting connected to the unit

Connect the service port to the RS232 serial port on the computer (option J3 required).

Click the "Utility Software 1" icon on the desktop or in the Windows Start menu.

Desktop icon:

Quick launch and Start menu icon:





The below window appears.



Plant Plant Pistorical alarms Trending Parameters Inputs / Outputs Options Copies		Open the Parameter list
<b>Solution DEIF utility</b>	offware Settings Trending Parameters Help	
	i 🖉 🔹 🚔 🚰 💽 🞱 🍞 📂 🖻 🍹 🔳 🗐 🖓 🎵 🖾 🎯 🖉 📄	
	Category Channel 🛆 Tex	X
		Click the "Upload parameters" icon
The follow	/ing screen will appear:	
Confirm		
۳	e parameters will now be read from the device. Do you want to proceed?	
	Yes No	

Read parameters from the device

Select "Yes" to start the parameter transfer.

After retrieving all the parameters, the device is ready to be configured.

# Basic configuration of a device using the utility software

When the parameters have been uploaded, the screen will look like below:

Đ	Odeany	Oami	in test	Adver	Volum	. Line	Teter	OutputA	Output?	Enabled	Hohaler
	Protection		1010 DHI Ownerstyl		1	TLA .		6.1	1	4	2
	Protection		1011 Dtf. curr. YTW		2	20 %		1674	NGA	7674	
	Protector		1012 Diff own V3N		3	65 N.		1428.	8,03,	84/1.	
	Protection		1820 DH. Cwrynt T			154		6,0	4		9
	Patedor		1821 Ditt care X1		5	100 %		1634	NOA	14/6.7	
	Protection		1822 DH own YIT		6	25 %		168.	NA	1475	
ma	Protection		1825 DH our Y27		7	20 %		- N(A)	N/A	14/4	
	Protection		1000 DHI Fired T		8	NUM The		0,05	4	6	2
	System		4011 Non. Frequency		26	50.)+tz		100.	N/A	14/6	
	System		4812 Non, Current		27	787 A		1424.	NUL	8675	
	System		4821 Ourrent preh		28	1000 A		7694	NA	NUL.	
	System		4022 Oursett nec		29	1 A		1628	NOL	16/12	
	System		4220 IDeltery KWV V		33	18 V		1	0	0	9
2	System		4231 Language		34	0		568.	5.05	34/6	
in i	System		4301 Status into LEO		35	164		NER	NA	1616	
	System		4310 Auto Ack.		36	我病		2	NUK	1675	
	System		4071 Password		37	-		7425	805	FLIA.	

### Nominal frequency

Double-click menu 4011 "Nom. Frequency" and the below pop-up will appear:

Parameter "Nom. Frequency" (Channel 4011)		Click this or use the slide bar to adjust the nominal frequency.
Enable High Alarm Inverse proportional Cable supervision		
Auto acknowledge Custom inhibit Write OK Cancel	<	After adjusting the fre quency, click "Write and "OK".

The nominal frequency has now been changed and downloaded to the device.

Use the same procedure to adjust nominal current (menu 4012) and CT ratio (menu 4021 and 4022).



For information about additional settings, please refer to the "Designer's Reference Handbook", document no. 4189340300.

DEIF A/S reserves the right to change any of the above.