


# TDU series

Touch display units for AGC and ASC controllers

## Connection guidelines

4139341369A



## 1. About the Communication guidelines

1.1 Symbols and notation.....	3
1.2 Symbols for hazard statements.....	3
1.3 Intended users .....	3
1.4 Legal information.....	4

## 2. About the TDU

2.1 Compatible controllers.....	5
2.2 Supervision mode and Asset mode.....	5

## 3. Connections

3.1 Ethernet cable requirements.....	6
3.2 Direct connection.....	6
3.3 Multiple display connection.....	7
3.4 Multiple controller connection.....	8

## 4. Data transfer loads

4.1 High data transfer loads.....	11
4.2 Low data transfer loads.....	11

# 1. About the Communication guidelines

## 1.1 Symbols and notation

### Symbols for general notes

**NOTE** This shows general information.



#### More information

This shows where you can find more information.



#### Example

This shows an example.



#### How to ...

This shows a link to a video for help and guidance.

## 1.2 Symbols for hazard statements



### DANGER!



#### This shows dangerous situations.

If the guidelines are not followed, these situations will result in death, serious personal injury, and equipment damage or destruction.



### WARNING



#### This shows potentially dangerous situations.

If the guidelines are not followed, these situations could result in death, serious personal injury, and equipment damage or destruction.



### CAUTION



#### This shows low level risk situation.

If the guidelines are not followed, these situations could result in minor or moderate injury.

### NOTICE



#### This shows an important notice

Make sure to read this information.

## 1.3 Intended users

This is the **Communication guidelines** for communication between the Touch Display Unit (TDU), and a variety of controllers.

The manual is for the designer who creates applications that use the TDU.



#### **More information**

See also [TDU 107 Core Installation Instruction](#) and [TDU 107 Extended Installation Instruction](#) for power supply connections and mounting of TDU units.

## 1.4 Legal information

### **Trademarks**

*DEIF* is a trademark of DEIF A/S.

All trademarks are the properties of their respective owners.

### **Third party equipment**

DEIF takes no responsibility for the installation or operation of any third party equipment, for example, a **genset**. Contact the **manufacturer** or third party equipment company if you have any doubt about how to install or operate the third party equipment.

### **Disclaimer**

DEIF A/S reserves the right to change any of the contents of this document without prior notice.

The English version of this document always contains the most recent and up-to-date information about the product. DEIF does not take responsibility for the accuracy of translations, and translations might not be updated at the same time as the English document. If there is a discrepancy, the English version prevails.

### **Copyright**

© Copyright DEIF A/S. All rights reserved.

## 2. About the TDU

### 2.1 Compatible controllers

This information applies to TDU software version **1.4.1** or later.

Controller	Controller types	Software version	TDU Asset mode	TDU Supervision mode	Notes
AGC 150	Generator, Mains, BTB	1.11 or later	●	●	
ASC 150	Solar, Storage	1.18 or later	●	●	
AGC-4 Mk II	Generator, Mains, BTB	6.00 or later	●	●	
ASC-4	Solar, Battery	4.27 or later	●	●	
AGC-4	Generator, Mains, BTB	4.72 or later	●	●	AGC-4 requires the Ethernet option N for connection.
ALC-4	Automatic load controller	4.13 or later		●	Only supports showing a symbol for the ALC-4, with no operating data.



### 2.2 Supervision mode and Asset mode

#### Asset

A single controller controlling e.g. a genset or a photovoltaic inverter is referred to as an asset.

#### Asset mode

In asset mode, the display shows the operation of the selected asset.

#### Supervision mode

When the display is set to supervision mode, it shows and monitors the entire plant. A single plant can have up to 40 assets. See the [AGC-4 Mk II data sheet](#) for the number of different assets possible in a single power management system.

The operator can tap any asset shown on the plant supervision screen to open that asset's control panel (does not apply to the ALC-4).




#### More information


See the [TDU Operator's manual](#) for how to operate asset mode or supervision mode.

## 3. Connections

### TDU 107 Core connections



### TDU 107 Extended, TDU 110 Extended and TDU 115 Extended connections



### 3.1 Ethernet cable requirements

The cables must not be longer than 100 metres from point-to-point.

The cable bend radius must not be tighter than the minimum bend radius specified by the cable manufacturers.

We recommend that you always follow the cable manufacturer's bend radius requirements and use use velcro-strips (and not cable-ties) for the Ethernet cables.


### 3.2 Direct connection

Connect the TDU directly to the DEIF controller for automatic functionality.

TDU model	Number of Ethernet ports	Comments
Core	1	
Extended	2	Bridged ports (ETH0 and ETH1)

**NOTE** For dynamic host configuration protocol (DHCP) you must use TDU Extended and connect the controller to ETH2 on the TDU Extended.

## Direct connection




## 3.3 Multiple display connection


Up to 10 displays can be connected to a single controller.

### Series connection

The series connection is only possible with TDU Extended models. All displays act as the primary (master) display.




### Ethernet switch connection




## 3.4 Multiple controller connection

### Redundant controller connection with two displays




Each controller is connected to one TDU. No redundancy configuration is needed in the TDUs.

## Master and slave connection with one display



You can connect one TDU to both the master (primary) and the redundant controller. Configure the IP addresses for the *Master* and *Slave* controllers in the *Communication settings* box (*Setup > Connect to controller*).


When the *Master/slave controller manual switch* is enabled, the TDU home screen has two buttons that show the active controller. You can use these buttons to change the active controller.




### More information

See *Control panel configuration settings* in the [TDU Operator's manual](#) for how to configure the Master/slave controller manual switch.

### Ethernet switch master and slave connection with one display



### Master and slave direct connection with one TDU Extended




## 4. Data transfer loads

### 4.1 High data transfer loads

Connections that place a high data transfer load on the controller (for example, a SCADA system) should be connected to the controller through a switch.

#### Recommend wiring to connect a SCADA system to a controller



### 4.2 Low data transfer loads

For setups that place a low data transfer load on the controller, connect the TDU Extended model directly to the controller and a service PC.

